

INSTALLING YOUR

BLINK CAMERA



Need technical support?

For help setting up your Blink camera, Wifi connection issues or questions on using the Blink app, please contact Blink support directly at:

1-833-392-5465


Or Blink online support and chat at:

support.blinkforhome.com


Although The Peep Show® loves and recommends the Blink camera, we have no association with Blink and are not equipped to handle technical support. We always refer our bird lovers directly to the Blink support center for the latest expertise on the Blink cameras and Blink app.

BLINK CAMERA INSTALLATION


Step 01




Step 02



Step 03




USE FRESH LITHIUM BATTERIES




BLINK CAMERA INSTALLATION

Step 04




Gently lift the silicon band and slide the camera into its mount. Lens should face down.

Step 05



For proper camera orientation, the Blink logo on the front of the camera should be adjacent to thumb grab.




Step 06



Replace camera mount back into The Peep Show. The thumb grab should face the front.

BLINK CAMERA INSTALLATION

Step 07




PRO TIP: Using your Blink app, test the camera alignment before installing in your backyard. The “welcome mat” should be nicely centered.

Step 08

DISABLING THE CAMERA'S BLUE RECORDING STATUS LIGHT



Your Blink camera has a blue LED status light on the front of the camera which turns on anytime recording is in progress. **This will disturb nesting birds and must be disabled.**

1. Launch your Blink app.
2. On the main screen, select the “controls” symbol adjacent to your camera’s name. It looks like this:

3. You will now be on the **Device Settings** screen. From here, select **General Settings**.
4. From the **General Settings** screen, look for **Status LED** about 2/3 down the screen.
5. Slide to the **Off** position. The Status LED is now disabled.

